


DS 2200 S (EPA 3) Brushcutter - Engine




DS 2200 S (EPA 3) Brushcutter - Engine



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61370016AR	Guard			Grigio; Grey	
2	3	3891037R	Screw				
3	6	3891047R	Screw				
4	6	3891009R	Screw				
5	1	58070143R	Cover				
6	1	61370276	Screen + Gasket				
7	1	094600126	Tube				
8	1	61370015R	Compl. muffler				
9	1	61370143R	Deflector				
10	1	3055112	Spark plug				
11	1	58070011R	Gasket				
12	2	58070166R	Ring				
13	1	61370085R	Crankcase assy				
14	2	61370208R	Piston ring				
15	1	61370252	Piston assy.				
16	1	61370253	Compl. cylinder				
17	1	58070045R	Shaft				
18	1	61370254	Set (Roller cage and washer)				
19	2	3034007R	Bearing				
20	3	3891051R	Screw				
20	1	58070022R	Gasket				
21	5	61280044R	Plug				
22	2	3050042R	Ring				
23	2	3025018R	Ring				
24	1	61370255	Gasket set				

DS 2200 S (EPA 3) Brushcutter - Starter assy and fuel tank




DS 2200 S (EPA 3) Brushcutter - Starter assy and fuel tank



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2501002R	Ignition coil				
2	1	50050127	Spring				
3	2	50160218	Spacer				
4	2	3891018R	Screw				
5	1	61370059R	Cable				
6	7	3891043R	Screw				
7	7	3893060R	Screw				
8	1	61370082R	Handle				
9	1	61370256	Flange kit				
10	1	61370024R	Rope				
11	1	61070036R	Spring				
12	1	61370022R	Pulley				
13	1	61240059R	Spring				
14	1	61370023R	Sprocket				
15	1	50160024	Screw				
16	1	61370230R	Starter assy			Rosso; Red	
17	2	61370014R	Pawl				
18	2	61070039R	Spring				
19	1	61370013R	Clutch driver				
20	1	3064034	Washer				
21	1	58070133R	Flywheel				
22	1	004400959R	Nut				
23	1	61070090R	Spring				
24	1	61070091R	Clutch				
25	1	61370257	Kit pin+Belleville washer+spacer ring				
26	5	3893009R	Screw				
27	1	61370031R	Flange				
28	1	4098377	Band				
29	1	61370083R	Clutch drum				
30	1	61070006R	Gasket				
31	1	61370033AR	Cover				
32	1	61250249R	Adjust. pin				
33	1	3024010R	Ring				
34	1	61372003R	Tank cap				
35	1	61070011AR	Breather valve				
36	1	3073001R	Breather Fule Pipe				
37	1	4161211	Bush				
38	1	61370038R	Tube				
39	1	61110162A	Bushing				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
40	1	094600450R	Fuel filter				
41	1	61370184R	Cover with fuel tank			Rosso; Red	
42	1	61370030R	Sleeve				
43	1	61370029R	Adaptor				
44	1	61370028R	Adaptor				
45	2	3914003R	Nut				
46	2	3891050R	Screw				

DS 2200 S (EPA 3) Brushcutter - Air filter




DS 2200 S (EPA 3) Brushcutter - Air filter



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	58070025R	Gasket				
2	1	61370001R	Insulator				
3	2	3891046R	Screw				
4	1	2318265R	Carburetor				
5	1	56570058R	Oil seal				
6	1	61370160R	Air filter				
7	1	61370258	Filter cover kit			Grigio; Grey	
8	1	61370008R	Knob				
9	1	3891063R	Screws				
10	1	61372008R	Filter support			Grigio; Grey	
11	1	2318817R	Air purge				
12	1	61370255	Gasket set				
13	1	61200196R	Gasket				
14	1	3073002R	Tube				
15	1	61370036R	Tube				

DS 2200 S (EPA 3) Brushcutter - Transmission




DS 2200 S (EPA 3) Brushcutter - Transmission



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3891043R	Screw				
2	1	61370052R	Clamp				
3	1	61370259	Handle			Grigio; Grey	
4	5	3893060R	Screw				
5	1	61370043R	Lever				
6	1	61370260	Lever group				
7	1	61370044R	Throttle lever				
8	1	3891037R	Screw				
9	1	61370220AR	Throttle cable				
10	1	61370032R	Cable				
11	1	61370045R	Tube Ø24				
12	1	61370261	Half handle kit			Grigio; Grey	
13	1	61370048R	Drive shaft				
14	1	3025026	Ring				
15	1	3024009R	Ring				
16	1	3035044	Bearing				
17	1	3035043	Bearing				
18	1	61170119AR	Gear case				
19	1	3906030	Screw				
20	1	3035045R	Bearing				
21	1	3034008	Bearing				
22	1	3025018R	Ring				
23	1	61170134	Seal ring				
24	1	61170122	Shaft				
25	1	61170123	Hub				
26	1	61170124	Thrust washer				
27	1	61110074R	Guard				
28	1	3933105	Nut				
29	1	61370262	Bevel gear set				
30	1	61370053R	Bevel gear				
31	1	3891050R	Screw				

DS 2200 S (EPA 3) Brushcutter - Accessories




DS 2200 S (EPA 3) Brushcutter - Accessories



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	63109001	Head "Load&Go				
2	1	63120041R	Insert				
3	1	63120040R	Nut				
4	1	63100018R	Kit spring				
5	1	63100020R	Ignition coil				
6	1	63100007R	Knob				
7	2	63120001R	Bushing				
8	1	63100005R	Cover				
9	1	4095641AR	Disk				
10	1	61372005R	Guard kit			Grigio; Grey	
11	1	3893016R	Screws				
12	1	61370161R	Blade				
13	2	3891043R	Screw				
14	2	094600054	Washer				
15	1	4160463AR	Single harness				
16	1	61370214R	Tool kit				
17	1	61370293	Labels kit				
18	1	61370161AR	Blade				
19	1	3893016R	Screws				
20	1	61370264	Guard kit			Rosso; Red	
21	1	61370249	Screws outfit				
22	1	61170124	Thrust washer				
23	1	61110074R	Guard				
24	1	3933105	Nut				
25	1	61370224	Set (Disk)			Rosso; Red	
26	1	61370057R	Guard				

DS 2200 S (EPA 3) Brushcutter - Carburetor



■ 4 — KIT RIPARAZIONE
REPAIR KIT

DS 2200 S (EPA 3) Brushcutter - Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318265R	Carburetor				Gaznik
2	2	2318837	Adjust. screw				Sruba
3	2	2318867	Cap				Korek
4	1	2318671	Repair kit				Zestaw naprawczy